


DVDO iScan Mini™ Setup Guide

iScan Mini Connections



SETUP

1. Connect iScan Mini using HDMI cable between sources and the display.
2. Apply power using USB cable direct from TV, if insufficient or no USB port on your TV, use USB wall adapter.
3. Connect AVR/Soundbar using optical S/PDIF if required.
4. If iScan Mini is hidden behind TV, an IR receiver dongle (sold separately – see users manual) can be used
5. iScan Mini comes in AUTO scaling and HIGH enhancement mode, use remote/OSD to adjust and save new enhancement settings or set custom scaling
6. Use display setup tools to adjust brightness/contrast/sharpness of display

For detailed setup and usage instructions, download the full users manual at dvdo.com/iscanmini



Remote Control

SCALING MODES

- Auto: Automatically scale to best resolution TV supports.
- DVDO: Scale to a specific resolution pre-set using menu system
- Off: Let the TV handle all scaling

ENHANCEMENT MODES

- Low: DVDO preset minor enhancement use for "good" video to make it pop
- High: DVDO preset extreme enhancement use for SD or internet video
- User 1/2: Programmable enhancement memories
- Off: No Enhancements
- Demo mode: Enables different split screen modes to test settings

TEST PATTERNS

See users manual for instructions – use to setup display

NAVIGATION

- Use to access and control the menu system
- Info: popup Information screen
- Audio: Change Audio modes for optical S/PDIF output



For more information and firmware updates, please visit www.dvdo.com

D V D O[®]

D V D O
iScan[™] Mini

VRS[®] ClearView[™]

Setup Guide